Mode/Channel			nction
			)/540
	2		vement
2	3		
	4		vement ment
3	5		t hanging
4	6		pen) ast pen) ces pen) slow to fast pen)
5	7		0
	8		ne
6	9		
		0-255	Zoom adjustment from small to big
	11	0-255	e:
		0-255	Continuous adjustment from far to near
	13	0-255	Continuous adjustment Fine
9	14		Auto Focus : Auto Focus Off
		51-100	7.5m
		101-150	10m
		0-255	AutoFocus Adjustment: Continuous adjustment
			Color Wheel

0-15	Open / white
16-31	Color 1
32-47	Color 2
48-63	Color 3
64-79	Color 4
80-95	Color 5
96-111	Color 6
112-127	Color 7
128-189	Forwards rainbow effect from fast to slow
190-193	No rotation
194-255	Backwards rainbow effect from slow to fast

Color Wheel Fine

0-255	Fine control of Tilt movement

Rotating gobos, cont. rotation

0-7	Open
8-20	Rot. gobo 1
21-33	Rot. gobo 2
34-46	Rot. gobo 3
47-59	Rot. gobo 4
60-72	Rot. gobo 5
73-85	Rot. gobo 6
86-98	Rot. gobo 7
99-111	Gobo 1 shake slow to fast
112-124	Gobo 2 shake slow to fast
125-137	Gobo 3 shake slow to fast
138-150	Gobo 4 shake slow to fast
151-163	Gobo 5 shake slow to fast

		22	0-255	Fixed gobo Fine indexing	
17	15	23		**Fixed wheel Animation :**	
			0-7	Close	
			8-255	Animation speed from slow to fast	
18	16	24		**Iris**	
			0-191	Max. diameter to Min.diameter	
			192-223	Pulse closing fast to slow	
			224-255	Pulse closing slow to fast	
		25		**Iris Fine**	
			0-255	Iris Fine	
19	17	26		**Rotating prism, Prism / Gobo macros:**	
			0-31	Open	
			32-127	Rot. Prism	
			128-135	Macro 1	
			136-143	Macro 2	2
			144-151	Macro 3	3
			152-159	Macro 4	4
			160-167	Macro 5	5
			168-175	Macro 6	6
			176-183	Macro 7	7
			184-191	Macro 8	8
			192-199	Macro 9	9
			200-207	Macro 10	
			208-215	Macro 11	
			216-223	Macro 12	
			224-231	Macro 13	
			232-239	Macro 14	
			240-247	Macro 15	
			248-255	Macro 16	
20	18	27		**Rotating prism:**	
			0-127	Prism indexing	
			128-189	Forwards prism rotation from fast to slow	
			190-193	No rotation	
			194-255	Backwards prism rotation from slow to fast	
		28		**Rotating Prism indexing Fine**	
			0-255	Fine indexing	
21	19	29		**Frost:**	
			0-127	Open	
			128-255	100% Frost	
22	20	30		**Control:**	
			0-19	Color&Gobo change normal	
			20-29	Color change to any position	
			30-39	Color&Gobo change to any position	
			40-59	No function	
			60-79	No function	
			80-84	All motor reset	8
			85-87	Scan motor reset	8
			88-90	Colors motor reset	8
			91-93	Gobo motor reset	8
			94-96	no function	
			97-99	Other motor reset	8
			100-119	Internal program 1 (secne1~8 of EEPROM)	1 (1~8)
			120-139	Internal program 2 (secne9~16 of EEPROM)	
			140-159	Internal program 3 (secne17~24 of EEPROM)	
			160-179	Internal program 4 (secne25~32 of EEPROM)	
			180-199	Internal program 5 (secne33~40 of EEPROM)	
			200-219	Internal program 6 (secne41~48 of EEPROM)	
			220-239	Internal program 7 (secne49~56 of EEPROM)	
			240-255	Sound Control	